




Safety Key Points for Trades



Tower Crane Worker (Erecting, Dismantling, Telescoping & Climbing)

Safety Starts With Me

1. When using a hydraulic jack for climbing of tower crane, please be aware of whether there is any leakage from the hydraulic jack or any strange noise when operating; whether there is any sign of instability or rough condition when moving upward or downward; and whether it is too fast or too slow when moving upward or downward.
2. When using internal climbing tower crane and the mast is being jacked up, the slewing brake of tower crane shall be locked.
3. When using internal climbing tower crane and the uplifting frame is used for jacking up process, the counter jib shall be rested right on top of the hydraulic jack position.
4. To ensure no one (including oneself) stands in any "FATAL ZONE" in the workplace, e.g. under the load and within mechanical operation zone, etc..
5. To ensure the safety trial of lifting of "3-3-3" (others stay away from 3m then lift the load at 300mm above ground for 3 seconds) is applied before formally carrying out lifting works.
6. Safety harness shall be worn and attached to the independent lifeline or anchorage when working at height.



For more
Safety Information
Please scan QR Code



Copyright

All contents of this document belong to the Construction Industry Council (CIC) / Hong Kong Institute of Construction (HKIC) and are protected by copyright.

Disclaimer

Whilst reasonable efforts have been made to ensure the accuracy of the information contained in this document, the CIC/ HKIC nevertheless would encourage readers to seek appropriate independent advice from their professional advisers where possible and readers should not treat or rely on this publication as a substitute for such professional advice for taking any relevant actions. For any enquiry, please contact 2100 9000.